

# Changing the printhead on your Merlin Scion Printer



1. Turn off the printer and open the printer lid. Remove the ribbon by pushing it to the left and lifting up.



2. Use a screwdriver and slowly push down in the gap as shown to loosen the printhead.



3. Detach the cable at the back of the printhead. Take your new printhead and plug in as shown.



4. Push the printhead into place one side at a time until it clicks in place. Reinsert the ribbon.

If you would like support, please contact our technical support team:  
email: [support@jepsonandco.com](mailto:support@jepsonandco.com) / tel: 0114 273 1151



**JEPSON & CO LTD**  
FIRST IN NUMBER PLATES  
*Celebrating 150 years*