



# Changing the ribbon on your Godex HD803i Printer



1. Push the green clips in and lift the ribbon carriage up. Pull the excess ribbon off the cardboard core.



2. Remove the waste ribbon roll by pushing right and lifting. Using the same motion, move the cardboard core to the top slot.



3. Load the new ribbon to the underside of the carriage.

Feed the ribbon under the carriage and up, then stick down to the front cardboard core.

Then, roll the ribbon to ensure this runs tight and lower the printer lid.

If you would like further support, please contact our technical support team on:

email: [support@jepsonandco.com](mailto:support@jepsonandco.com)  
tel: 0114 273 1151



**JEPSON & CO LTD**  
FIRST IN NUMBER PLATES  
*Celebrating 130 years*