

Aligning the Printhead on your Godex G500 Printer



This is not something you will have to do often. If you've been advised that the alignment isn't right, please check with our IT support team or your Area Manager for advice.

To align the printhead, simply take a screwdriver and tighten the screws slightly (around half a turn) on both sides of the printer, near the green clips as shown. You can now continue printing.

If you would like further support, please contact our technical support team on:

email: support@jepsonandco.com
tel: 0114 273 1151